

How to activate the ILS?

The ILS turns on automatically at an airports approach. It is also to activate by setting a flightpath under "Navigation". At the Boeing 747 the ILS appears in the glass cockpit right of the artificial horizon. A direction indicator in the middle and a height indicator on the right are the indicators for the glide path.



From:

<https://www.aerofly.com/dokuwiki/> - **Aerofly FS Wiki**

Permanent link:

https://www.aerofly.com/dokuwiki/doku.php/faq:how_to_activate_the_ils

Last update: **2017/01/17 16:56**

